Review all airlines for suitability of use and type of fastener to secure the fitting. • Ensure the hoses used are made to British Standard for the application you are using. • Ensure the fitting is the correct size for the hose being used. • When adjusting any airline fitting, use a fresh, clean and undamaged part of the correct hose when fastening the fitting. • Use the appropriate fastener for your pressure applications. Seek advice from a hose specialist. • High pressure applications should use mechanical fabricated fitted or crimped fastenings. • The preferred mechanical fastenings shown below can be done in house with the correct equipment and training.

Mechanical cramped fitting **Crimped ring fitting**

LOCATION:	**CONCRETE PRODUCTS PLANT**	**ALERT STATUS:**	**Normal**
ACTIVITY:	**MAINTENANCE & HOUSEKEEPING**	**DATE ISSUED:**	**18/10/2019 15:15:53**
SUB ACTIVITY:	**N/A**	**INCIDENT No:**	**01529**